

Verlegehinweise XP Silent Rolle 2 mm

XP Silent Rolle ist ein hochdämmender, extrudierter Polystyrolschaum und bestens geeignet für schwimmend verlegte Parkett-, Laminat- und Korkbodenbeläge in normal beanspruchten Räumen.

Vorbereitung: Der Untergrund muss bei der Verlegung entsprechend der VOB DIN 18 365 sauber, trocken und rissfrei sein. Die Ebenheit des Untergrundes soll mindestens den Anforderungen der DIN 18 202 (Ebenheitstoleranzen im Hochbau, Tabelle 3, Zeile 3) entsprechen.

Raumklima: Die Unterlage kann bei einer Raumtemperatur ab ca. 15°C und einer relativen Luftfeuchte von ca. 65% verlegt werden.

Die Unterlage sollte mindestens 12 Stunden vor der Verarbeitung im Verlegebereich akklimatisiert werden. Die Stärke des Bodenbelags sollte 11 mm nicht überschreiten. Legen Sie XP Silent Rolle im Raum aus und schneiden diese passend mit einem Wandabstand von 2 – 3 mm zu. Legen Sie die weiteren Bahnen stumpf an die zuletzt verlegte Bahn an und schneiden diese wie vor zu. Überkleben Sie die Nähte mit einem Alu-Folien-Dichtband, damit aufsteigende Feuchtigkeit aus dem Untergrund auch an den Nähten gleichmäßig verteilt wird. Kleben Sie auch rundum an den Wänden ein Alu-Folien-Dichtband entlang. Dazu fixieren Sie das Band etwa zur Hälfte an der Unterlage und zur anderen Hälfte an der Wand.

Verlegung: Diese Unterlage sollte ausschließlich auf nichtmineralischen Untergründen verlegt werden. Für mineralische Untergründe empfehlen wir die Verwendung von XPS Rolle ALU 2,2 mm.

Achtung: Bei der Verlegung darf das Material nicht begangen werden. Zur Vermeidung von punktuellen Belastungen Planken auslegen. Für die Verlegung des Oberbodenbelags bitte die Vorgaben des Herstellers beachten.

Hinweis: Nicht im Freien lagern, vor Sonneneinstrahlung schützen.

Laying instructions XP Silent Roll 2 mm

XP Silent Roll is a highly insulating, extruded polystyrene foam and is ideally suited for floating parquet, laminate flooring and cork flooring in rooms with normal use.

Preparation: for the installation, the substrate must be clean, dry and free of cracks in accordance with VOB DIN 18 365. The flatness of the substrate must at least meet the requirements of DIN 18 202 (flatness tolerances in building construction, Table 3, Line 3).

Indoor climate: The underlay can be installed at a room temperature of about 15°C and a relative air humidity of about 65%.

The underlay should be placed for acclimatisation in the installation area at least 12 hours before being installed. The thickness of the floor covering should not exceed 11 mm. Place the XP Silent roll in the room and cut it to fit with a wall distance of 2 - 3 mm. Place the other strip bluntly against the strip that has just been laid and cut as before. Tape the seams with aluminium foil sealing tape, so that humidity rising from the ground can be evenly distributed across the seams. Fix also some aluminium foil sealing tape all around the walls. To do this, place the tape half on the underlay and half on the wall.

Installation: this underlay should be installed exclusively on non-mineral substrates. For mineral substrates, we recommend using XPS roll ALU 2.2 mm.

Caution: You must not walk on the material during the installation. Lay planks to avoid any point loads. When laying the top floor covering, please follow the manufacturer's instructions for use.

Note: Do not store outdoors; protect against direct sunlight.