Verlegehinweise

Laying instructions

Profil anlegen:

Das Profil wir in die Innenecke der Tritt- und Setzstufe gelegt. Legen Sie hierzu den aufgehenden Schenkel des Profils an die Setzstufe passend an.

Verschrauben:

Mit einem 5 mm Bohrer die zuvor vom Profil auf die Tritt- und an Setzstufe übertragenen Bohrungen für die Dübel bohren. Die Bohrlöcher absaugen, damit keine Bohrspäne in den Löchern und auch keine störenden Bohrspäne unter dem Profil verbleiben. Entsprechend den Bohrlöchern verwenden Sie bitte geeignete Dübel und Schrauben. Führen Sie nun die Dübel in die Bohrlöcher so ein, dass diese komplett in den Bohrlöchern versenkt sind. Bei Holzuntergründen kann die geeignete Schraube direkt durch die Befestigungslöcher in den Untergrund eingeschraubt werden.

Verlegen des Bodenbelags:

Damit der Bodenbelag ohne sichtbare Kante zwischen dem Innenwinkel und der Treppenkante liegt, empfehlen wir den Zwischenraum per Nivellierspachtel auszugleichen. Verwenden Sie hierzu dem Untergrund entsprechend geeignete Ausgleichsmassen oder verklebbare Unterlagsmattensysteme.



Starke Verbindung Kluge Technik Strong contacts Clever technology

Lay on the profile:

The profile is placed in the inner corner of the tread and riser. To do this, fit the rising leg of the profile to the riser.

Screwing:

Use a 5 mm drill to drill the holes for the dowels previously transferred from the tread to the tread and riser. Vacuum the holes so that no drill dust remains in the holes and no troublesome drill cuttings remain under the profile. According to the drilled holes please use suitable dowels and screws. Now insert the dowels into the drill holes so that they are completely sunk in the holes. For wooden subfloors, the appropriate screw can be screwed directly through the mounting holes in the ground.

Laying the flooring:

To ensure that the floor covering lies between the inner angle and the edge of the staircase without a visible edge, we recommend levelling the gap with a levelling filler. For this purpose, use appropriate levelling compounds or glued underlay mat systems to suit the subfloor.





